
OVERVIEW

This guide provides you with everything you need to get started. If you need additional information on features and services, please select one of these helpful options:

- On your phone, tap the **My Account** icon on the Widget Bar. Tap **Help & Support**.
- Refer to your User Guide.
- Visit **www.t-mobile.com**.

Having Fun

Turn to the **Having Fun** section of this booklet to learn what else your new phone can do.

TABLE OF CONTENTS

Introducing Your Phone	4
Home Screen	5
Keypads	6
Touch Screen Navigation.....	8
Service Activation	9
SIM Card	10
Battery	12
Power	13
Call Functions	13
My Account	14
Contacts.....	15
E-mail Setup.....	16
myFaves® Setup	18
Bluetooth® Setup.....	24
Emergency Dialing.....	26
Caring for Your Phone.....	27
Tips for Safety	28


INTRODUCING YOUR PHONE

T-Mobile® Tap™



HOME SCREEN

The Home screen is your starting point for using all the applications and widgets on your phone.




KEYPADS

Your phone has two on-screen keypads: a standard keypad with multiple letters per button and a full QWERTY keypad that is similar to your computer keyboard.

QWERTY keypad

To display the on-screen QWERTY keypad when creating a message, rotate the phone horizontally in a counterclockwise direction.



Standard keypad

Your standard keypad supports four text modes:

- **T9® Prediction mode:** This mode allows you to enter words with only one tap per letter and the phone predicts the word you want. For example, to enter **run**, tap the buttons with the letters **pqrs**, **tuv**, and **mno**.
- **Traditional mode:** This mode allows you to enter letters by tapping the same button until the correct letter displays. For example, to enter **run**, tap the


pqrs button three times, the **tuv** button two times, and the **mno** button two times.

- **Number mode:** This mode allows you to enter numbers.
- **Symbol mode:** This mode allows you to enter symbols such as punctuation marks.

Change text mode:

When creating a message, tap the **T9** button to turn the T9 Prediction mode on or off.

To enter symbols, tap the **SYM** button. Tap the arrows to scroll up or down and tap the desired symbol.



TOUCH SCREEN NAVIGATION

- Gently tap an item to open or activate it.
- Firmly touch and slide your finger up or down the screen to scroll through lists of menu items. Scrolling requires a firmer touch on the screen than the gentle tap required to open menu items.
- Flick the screen in an upward motion to quickly scroll through a list.



SERVICE ACTIVATION

If you are a new T-Mobile customer and your service has not been activated, simply call Customer Care at 1-800-937-8997 from your landline phone and a T-Mobile Activations representative will assist you.

You will need the following information when activating service:

- Service Agreement and agent code on your Agreement
- Your name, home address, home phone, and billing address
NOTE: For business and government accounts, please provide the name of your company or government agency, address, and tax ID.
- Your Social Security number, current driver's license number, and date of birth for credit check purposes
- Your choice of T-Mobile rate plan and services (see www.t-mobile.com for latest plan information)
- SIM serial number and IMEI number (located on the box bar code label)

By activating service, you acknowledge that you have read, understand, and agree to be bound by each of T-Mobile's Terms and Conditions and your Service Agreement.

SIM CARD

Your Subscriber Identity Module (SIM) card identifies you to the wireless network. Your phone will not work without the SIM card. To insert the SIM and battery:


1. Detach your SIM card.




2. Press down on the back cover above the camera and slide the battery cover away. Lift and remove the battery.



3. Slide the SIM card into the holder with the notched corner facing out of the slot.



4. Replace the battery by aligning the golden contacts on the battery with the contacts in the battery compartment. Replace the back cover and click into place.




BATTERY

You can charge your phone using the charger cable connected to a wall outlet or by using the USB cable connected to your computer.

Charge using a charger cable

To charge, plug the small end of the charger cable into the charging port on the top of your phone. Plug the other end of the charger into a wall outlet.



Charge using a USB cable

To charge, plug the small end of the USB cable into the charging port on the top of your phone. Plug the other end of the USB cable into the USB port of your computer.

POWER

To turn your phone on or off, press and hold the **Power** key on the top of the phone.

CALL FUNCTIONS

Make calls

1. From the Home screen, tap **Dialer**.
2. Enter the number and press the green **Send** key.

Answer & end calls

To answer a call, press the green **Send** key.

To end a call, press the red **End** key.

Call and set up voicemail

1. From the Home screen, tap **Dialer**.
2. Touch and hold **1**.
3. Follow the tutorial to set up voicemail.

To reset the voicemail password to the last four digits of your phone number, enter **#793#** and press the green **Send** key.

To call voicemail, from the Home screen, tap **Dialer** and touch and hold **1**.

MY ACCOUNT

Access account information


You can view your monthly usage, bill summary, and other account information on your phone. To view:

1. From the Home screen, tap the arrow to open the Widget Bar.
2. Scroll to and tap the **My Account** icon.
3. Tap **Bill Summary**, **Pay Bill**, **Plan & Services**, or **Help & Support**.

CONTACTS

Add contact

1. From the Home screen, tap **Contacts**.
2. Tap **Add New contact**.
3. Tap the **First Name** text field.
4. Enter the contact's first name.
5. Tap **OK**.
6. Enter additional contact information.
7. Tap **Save**.




Call contact

1. From the Home screen, tap **Contacts**.
2. Tap the contact you wish to call.
3. Press the green **Send** key.
4. If required, tap the desired phone number to call.

E-MAIL SETUP

Add e-mail account

1. From the Home screen, tap **Menu**.
2. Tap **E-mail**.
3. Tap the **E-mail address** text field.
4. Enter your e-mail address.
5. Tap **OK**.
6. Tap **Next**.
7. Tap the **Password** text field.
8. Enter your password.
9. Tap **OK**.
10. Tap **Next**.
11. If necessary, tap **POP3** or **IMAP4**.
12. Tap **Next**. The phone searches for and downloads your e-mail messages.
13. Tap **OK**.



Delete e-mail account

1. From the Home screen, tap **Menu**.
2. Tap **E-mail**.
3. Tap **E-mail Wizard**.
4. Press the **Navigation** key down to scroll to the account you wish to delete.
5. Tap **Options**.
6. Tap **Delete**.
7. Tap **Yes**.


myFaves[®] SETUP

myFaves is an optional calling plan. Benefits of signing up to myFaves:

- Unlimited nationwide calling to any five U.S. numbers, on any network (even landlines)*
- Calling, text messaging, e-mail, and photo sharing**
- No domestic roaming or domestic long-distance charges
- Personalize contacts with favorite pictures and downloadable icons**

* myFaves only applies to calls directly between two people and allows unlimited nationwide calling to five U.S. numbers. You can change myFaves numbers once/month.

** Separate purchase/download charges may apply. Separate charges may apply to send/receive domestic/international text/picture messages and to send/receive domestic/international e-mail.



Subscribe to myFaves[®]

To subscribe, go to www.t-mobile.com. When you have subscribed to myFaves, you will see five circles on the main screen a few minutes after you power on your phone.

Tip: When you restart your phone, your myFaves circles will move to the Widget Bar. Simply scroll to and tap the myFaves icon  on the Widget Bar to access your myFaves contacts.

Add myFaves contact

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap an unassigned circle.
3. Tap one of the following:
 - **Create New:** Tap the **Name** text field. Enter the contact's name and tap **OK**. Tap the **Number** text field. Enter the contact's phone number and tap **OK**.
 - **Add from contacts:** Tap the contact.

Assign an icon to myFaves

4. Tap the icon at the top of the screen.
5. Tap one of the following:
 - **Take picture:** Frame the subject and press the **Center Select** key to take a picture. Tap **Add**.
 - **Pictures:** Tap the picture. Touch and slide the circle

to the desired location. Tap **Select**. Tap **Select** again.

- **myFavesIcon:** Tap the desired icon.
- **Others:** Tap the picture. Touch and slide the circle to the desired location. Tap **Select**. Tap **Select** again.

6. Tap **Save** or continue to **Step 7** to assign a ringtone.

Assign a ringtone

7. Scroll up and tap **Ring tone**.
8. Tap one of the following:
 - **Voice recorder:** Tap **Record** and speak your message. Tap the **Stop** button. Tap **Options>Select**.
 - **Music:** Tap the desired music file.
 - **Ringtones:** Tap the desired ringtone.
 - **Others:** Tap the desired audio file.
9. Tap **Save**.


An hourglass displays in the circle while the contact is being added to the contacts list. You can use your phone during this time. Once the contact is added, you will receive a confirmation message and the hourglass is replaced by your new contact.

Edit a myFaves contact

Names and icons: You can change names and icons at any time.


Phone numbers: You can only change a contact's phone number once per calendar month. If a number change is not allowed, you will receive an error message explaining why.

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap the contact you wish to edit.
3. Tap **Options**.
4. Tap **Edit**.
5. Edit the contact's name, phone number, icon, or ringtone.
6. Tap **Save**.
7. Tap **Yes**.




Replace a myFaves contact

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap the contact you wish to edit.
3. Tap **Options**.
4. Tap **Replace contact**.
5. Tap one of the following:
 - **Create New:** Tap the **Name** text field. Enter the contact's name and tap **OK**. Tap the **Number** text field. Enter the contact's phone number and tap **OK**.
 - **Add from contacts:** Tap the contact.
6. Tap **Save**.
7. Tap **Yes**.



Move a myFaves contact to another circle

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap the contact you wish to edit.
3. Tap **Options**.
4. Tap **Change order**.
5. Touch and slide the contact to the desired location.
6. Tap **Save**.



BLUETOOTH® SETUP


Your phone comes with Bluetooth technology, which is a wireless technology that enables a data connection between your phone and a Bluetooth wireless headset (headset sold separately).

Prepare a Bluetooth wireless headset

To pair your phone with a Bluetooth headset, make sure that your headset is fully charged and that you put the headset into pairing mode. See your Bluetooth headset's manual for more information.

Turn on the Bluetooth feature and pair with a headset

1. From the Home screen, tap **Menu**.
2. Tap **Bluetooth**.
3. Tap **Bluetooth** again.
4. Tap **On**.
5. Tap **Search**. Your phone scans for available Bluetooth phones.
6. Touch the headset to select it.
7. Enter the PIN if needed. The default PIN is usually **0000**.
8. Tap **OK**.



EMERGENCY DIALING

While all phones are equipped with 911 emergency calling, this phone may or may not permit its location to be approximated during a 911 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 911 calling system that are required to be installed by the local 911 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped or refused. The phone's approximate location is transmitted to the local 911 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

CARING FOR YOUR PHONE

MAKING IT LAST

Your phone is a complex electronic device; think of it as a mini-computer. Here are some hints that should help you extend the life of your new phone.

Phones aren't cheap, so keep yours in a safe place—away from children who may find it fun to see if the phone sinks or floats, and away from dogs that find plastic-coated products to be irresistible chew toys.

Water will damage your phone and accessories—even a small amount such as water droplets from a soda in your car cup-holder, melting snowflakes, tears of joy, squirt-gun cross-fire or steam from hot water in the kitchen or bathroom.

Use only batteries and accessories from the original manufacturer of your phone. Non-approved accessories can cause damage to you or your phone and shorten the phone's life. Hint: If it's being sold out of someone's car trunk, walk away.

If your charger or any other accessory is damaged, replace it or take it to a qualified service dealer. Do not attempt to operate your phone charger if it has received a sharp blow, been dropped, thrown from a speeding motorcycle or is otherwise damaged; doing so may damage your phone.

TIPS FOR SAFETY

Check with your doctor if you have a pacemaker or hearing aid in order to ensure that cell phone usage is safe with your phone. If you have questions about the interaction of cellular radio frequency and any other electronic equipment, ask the manufacturer of the equipment if cell phone radio frequencies will disrupt the equipment's performance.

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:

- Assess road conditions before answering. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone option before you start moving.
- If your phone rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Program frequently used numbers into your speed dial for easy one-touch dialing.
- Remember that laws prohibiting or restricting the use of a mobile phone while driving may apply in your area.



having fun

Table of Contents

E-mail	2
Text Messaging	4
Picture Messaging	7
Video Messaging	9
Instant Messaging.....	10
myFaves®	14
Call myFaves Contact	14
Send Text Message	14
Send Instant Message.....	15
Send Multimedia Message.....	16
Send E-mail Message	18
Send Audio Postcard SM	19
Browsing	20
Accessories for Your Phone	21
Additional Information	22

E-mail

Your phone comes with e-mail so you can stay connected while you are on the go with Yahoo!®, AOL®, and other popular e-mail providers. Setting up e-mail on your phone is easy—enter your e-mail address and password and your phone automatically receives e-mail from your e-mail account. You can read, send, reply, and even delete e-mail so you can keep in touch whenever you want.

Read e-mail message

1. From the Home screen, tap **Menu**.
2. Tap **E-mail**.
3. Tap **Inbox**.
4. Tap a message to read.

TIP: If you do not see an inbox, refer to the **E-mail Setup** section in this guide to set up an e-mail account.

Send e-mail message

1. From the Home screen, tap **Menu**.
2. Tap **E-mail**.
3. Tap **Create E-mail**.
4. Tap the **To** text field.
5. Tap one of the following:
 - **Add from contacts:** Tap the contact(s) and tap **OK**.
 - **Enter E-mail:** Enter the e-mail address and tap **OK**.
6. Tap **Back**.
7. Tap the **Subject** text field.
8. Enter a subject and tap **OK**.
9. Tap the **Text message** text field.
10. Enter your message and tap **OK**.
11. Tap **Options**.
12. Tap **Send**.



Separate charges may apply to send/receive/read domestic/international e-mails.

Text Messaging

Send text message

1. From the Home screen, tap **Menu**.
2. Tap **Messaging**.
3. Tap **Create message**.
4. Tap the text field.
5. Enter your message.
6. Tap **Send**.
7. Tap one of the following:
 - **Add from contacts:**
Tap the contact(s) and tap **OK**.
 - **New number:** Enter the number and tap **OK**.
 - **Enter E-mail:** Enter the e-mail and tap **OK**.
 - **My album online:**
Tap to send to **My Album**.
8. Tap **Send**.



Read text message

Your phone notifies you when you have a new text message. To read, tap **Unread message**. To read by going to the Menu:

1. From the Home screen, tap **Menu**.
2. Tap **Messaging**.
3. Tap **Inbox**.
4. Tap the message to read.

Separate charges may apply to send/receive domestic/international text messages.



Picture Messaging

Send picture message

1. From the Home screen, press the **Camera** key on the lower right side of the phone.
2. Frame your subject and press the **Center Select** key to take a picture.
3. Tap **Send as**.
4. Tap **As Message**.
5. Tap the text field.
6. Enter your message.
7. Tap **Send**.
8. Tap one of the following:
 - **Add from contacts:** Tap the contact(s) and tap **OK**.
 - **New number:** Enter the number and tap **OK**.
 - **Enter E-mail:** Enter the e-mail address and tap **OK**.
 - **My album online:** Tap to send to **My Album**.
9. Tap **Send**.



Separate charges may apply to send/receive domestic/international picture messages.



Video Messaging

Send video message

1. From the Home screen, press the **Camera** key on the lower right side of the phone.
2. Tap **Camera**.
3. Tap **Video camera**.
4. Frame your subject and press the **Center Select** key to start recording.
5. Press the **Center Select** key again to stop recording.
6. Tap **Send as**.
7. Tap **As Message**.
8. Tap the text field.
9. Enter your message.
10. Tap **Send**.
11. Tap one of the following:
 - **Add from contacts:** Tap the contact(s) and tap **OK**.
 - **New number:** Enter the number and tap **OK**.
 - **Enter E-mail:** Enter the e-mail address and tap **OK**.
 - **My album online:** Tap to send to **My Album**.
12. Tap **Send**.



Separate charges may apply to send/receive domestic/international video messages.

Instant Messaging

Access instant messaging

Nimbuzz combines all of your contacts from Windows Live Messenger®, Yahoo!® Messenger, AIM®, Google Talk™, and more. With one login, you can communicate with all of your contacts at once. To create a Nimbuzz account:

1. From the Home screen, tap **Menu**.
2. Tap **Messaging**.
3. Tap **IM**.
4. Tap **Create new account**.
5. Tap the **Username** text field.
6. Tap the text field.
7. Enter your username and tap **OK**.
8. Tap **OK** again.
9. Tap the **Password** text field.
10. Enter your password.
11. Tap the **Repeat Password** text field.
12. Enter your password.
13. Tap the **Characters from image** text field.
14. Enter the characters displayed in the image.
15. Tap **Create**.

Separate charges may apply to send/receive domestic/international instant messages.

James05
movie @ 7.15. don't b late.

0207_lana
no worries. on my way.

James05
see you then!

Add contacts

1. From the Home screen, tap **Menu**.
2. Tap **Messaging**.
3. Tap **IM**.
4. Enter your Nimbuzz username and password.
5. Tap **Online**, **Away**, **Busy**, or **Appear offline** for your initial status.
6. Tap **Sign in**.
7. Tap **Menu**.
8. Tap **Add contact**.
9. Tap the desired IM account.
10. Tap **Yes** to download all of the contacts from your account.
11. Enter your account username and password.
12. Tap **OK**. Your contacts are downloaded to your phone.



Send instant message

1. From the Nimbuzz main screen, tap the contact you wish to chat with.
2. Tap **Start chat**.
3. Press the **Center Select** key.
4. Tap the text field.
5. Enter your message.
6. Tap **OK**.
7. Tap **Menu**.
8. Tap **OK** to send your message.



Call myFaves® contact

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap a myFaves contact and press the green **Send** key to call.

Send text message

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap a myFaves contact.
3. Tap **Message**.
4. Tap the text field.
5. Enter your message.
6. Tap **Send**.

Send instant message


1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap a myFaves contact.
3. Tap **IM**.
4. Sign in to communicate with your myFaves contact.



Separate charges may apply to send/receive domestic/international text and instant messages,

Send multimedia message

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap a myFaves contact.
3. Tap **Message**.
4. Tap the text field.
5. Enter your message.
6. Tap **OK**.
7. Tap one of the following:
 - **Add picture icon:** Tap **Take picture**. Frame your subject and press the **Center Select** key. Tap **Add**.
 - **Add Video icon:** Tap **Record video**. Frame your subject and press the **Center Select** key to start recording. Press the Center Select key again to stop. Tap **Add**.
8. Select **Options**.
9. Tap **Send**.



Separate charges may apply to send/receive domestic/international multimedia messages.

Send e-mail message

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap a myFaves contact.
3. Tap **E-mail**.
4. If the contact does not have an e-mail address, tap **Yes** to add an address. Tap the **@** text field. Enter the e-mail address and tap **OK**. Tap **Save** and **Yes** to save the contact. When the contact is saved, tap **E-mail** again.
5. Tap the **Subject** text field.
6. Enter a subject and tap **OK**.
7. Tap the **Text message** text field.
8. Enter your message and tap **OK**.
9. Tap **Options>Send**.

Separate charges may apply to send/receive domestic/international Audio Postcards and to send/receive/read domestic/international e-mails.

Send Audio PostcardSM

1. From the Home screen, tap the myFaves icon on the Widget Bar.
2. Tap a myFaves contact.
3. Tap **Audio**.
4. Frame your subject and press the **Center Select** key.
5. Tap **REC** and speak your message.
6. Tap **Stop** icon to stop recording.
7. Tap **Send**.



Browsing

Experience the mobile Web like never before with T-Mobile's new web2goSM experience. New features include a browser optimized for viewing on your phone, a customizable start page for easy access to information, a powerful built-in Web search engine, and account information viewable on your phone.

For more information about these services, see the web2go section of your services guide or visit t-mobile.com/shop/addons.

Access web2go

From the Home screen, tap **Web**.

Download content

You can download ringtones, wallpaper, games, applications, myFaves icons, and CallerTunes[®] from your phone. To download:

1. From the Home screen, tap **Web**.
2. Tap the **Downloads** tab.
3. Tap the desired content to download.

Full access to the Web requires the purchase of a compatible data plan. Not all sites are optimized for Web browsers. Separate, additional charges may apply for downloads; actual content available for download may vary.

Accessories for Your Phone

Whether you are looking for a charger, a fashionable carrying case, a Bluetooth[®] headset or just want to browse for fun extras for your phone, T-Mobile is the place to shop for accessories. Here are a few examples....

Memory Card



Car & Wall Charging System



To purchase accessories for your phone, visit T-Mobile.com, call 1.800.204.2449 or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

Additional Information

myFaves: myFaves only applies to calls directly between two people and allows unlimited nationwide calling to 5 U.S. numbers. You can change myFaves numbers once/month.

Messaging/Features: You will be charged for all data sent by or to you through the network, regardless of whether received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications.

Downloads: Additional charges apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited; may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. See brochures, and **T-Mobile's Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details.

Yahoo!® is a registered trademark of Yahoo! Inc. The Bluetooth® word mark and logo are owned by the Bluetooth SIG, Inc. and are used by T-Mobile under license. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. myFaves, the myFaves design and CallerTunes are registered trademarks, Tap is a trademark, and web2go and Audio Postcard are service marks of T-Mobile USA, Inc. All other brands, product names, company names, trademarks, and service marks are the property of their respective owners. ©2009 T-Mobile USA, Inc.